

## IMS CATCH CAN INSTRUCTIONS.

To install this catch can, you will need a heat gun, a razor, in addition to some dikes and a 5mm allen wrench.

1. Locate the OEM breather port and cut off with a sharp razor.



2. Place provided clamp over the end the tube.



3. Use a heat Gun to warm up the plastic



4. Slide on the hose to the bottom of the catch can. Some muscle may be required, and crimp the clamp to secure it in the proper orientation.



5. Place washers under the feet of the catch can.



6. Tighten provided hardware till snug



7. Enjoy zero mess moving forward

